Mic and Speaker Plugs for Kenwood Handhelds

TH-78, TR-2600 and newer



Mic Plug (3.5 mm stereo) to Mic Jack
Ring of plug - Transmit Signal through a 0.1 microfarad capacitor
Sleeve of plug - PTT

Speaker Plug (2.5 mm mono) to Speaker (SP) Jack
Tip of plug - Receive Signal
Sleeve of plug - Ground

Note: Turn off battery saver

Or, wire with a transformer instead of a capacitor